

Instructions: Fixing a Stuck Ink Pad



Step 1:

Hold the ink pad like this.




Step 2:

Place your thumb on the corner like this.



Step 3:

Use your thumb to pop out the top corner to break the vacuum holding the pad shut.



Step 4:

Press the joint back into your ink pad. Keep in mind this might leave a dent in the side of your pad. This will not affect the pads quality.



The most common reason ink pads get stuck like this is because there is a sort of vacuum that happens during manufacturing. Once you break the vacuum, the ink pad works like a charm, just like it's supposed to!

Step 5:

Push the pad closed again. Your ink pad should now open and close easily like it is supposed to!